



Pocono Fabricators

160 Gamma Drive, Pittsburgh, PA 15238-2989
Phone (610) 400-1885 Fax (610) 400-1863

www.pre-krete.com
info@pre-krete.com

May 2006

GUIDE SPECIFICATION #PKEMC - APPLICATION **OVER CONCRETE INCLUDING AN EXPANDED METAL ANCHORING SYSTEM**

NOTE: This guide specification points out various installation procedures but cannot cover all variations in field conditions. Therefore, experienced applicators may sometimes deviate from these procedures to suit specific field and service conditions.

SERVICES REQUIRED -- to furnish and install a corrosion resistant mortar lining in accordance with the following specifications. This work to be completed as close as possible to the anticipated start-up date. All work is to be inspected at each stage by the party responsible for quality control.

SCOPE

- a. The corrosion resistant mortar lining shall be applied to protect the metal in accordance with these specifications. The application shall include preparation of the steel surface, welding in an expanded metal anchoring system, mixing and applying the mortar lining using specified materials and application procedures.
- b. The installation of the lining shall be accomplished by a franchised representative of the manufacturer of the corrosion resistant mortar or by crews experienced in the field installation of gunned mortar linings.
- c. Installation is to be accomplished when the steel temperature is between 40°F to 90°F for a majority of the time -- excursions for short intervals are permitted. If temperatures will be below or above this range for a majority of the time, heating or cooling of the area should be included to insure a sound lining application.

MATERIALS

LINING

- a. The lining shall be a corrosion resistant cement, Pre-Krete, as manufactured by Pocono Fabricators, 160 Gamma Drive, Pittsburgh, PA. The mortar lining shall contain no free lime and not less than 25% silica. It shall be composed of a low water soluble hydraulic binder which is



Pocono Fabricators

160 Gamma Drive, Pittsburgh, PA 15238-2989
Phone (610) 400-1885 Fax (610) 400-1863

www.pre-krete.com
info@pre-krete.com

completely inorganic and non-toxic.

The mortar lining material shall be pre-blended in the plant of the manufacturer so that it is totally homogeneous and completely uniform. The mortar lining material shall be delivered to the job site in 50 lb. paper bags. Only the addition of clean, cool water will be used, no other ingredients will be added. Use of portland cement will not be permitted.

- b. Prior to installation, certified laboratory data shall be submitted which verifies that the mortar lining meets the following minimum requirements:
1. Water absorption of the mortar lining (when tested in accordance with Military Specification MIL-T-12295) shall not be more than 10% of its dry weight.
 2. Compressive strength of the mortar lining (when tested in accordance with ASTM Method C109-78) shall be at least 5,000 psi after 3 days. Tensile strength (when tested in accordance with ASTM Method C190-77) shall be at least 600 psi after 3 days.
 3. The lining shall have approximately the same coefficient of expansion as medium steel. This shall be verified by tests where the mortar lining has been applied to medium steel rings, heated up to 350°F, then plunged into tap water at 40°F. Tests shall be repeated 100 times and shall indicate that the lining is unaffected by this temperature variation.

WATER

Water for mixing the mortar lining shall be cool potable water, free from objectionable quantities of silt, organic matter, alkali, salts and other impurities.

SURFACE PREPARATION

- a. The concrete surface shall be cleaned to remove oil, dirt, grease and loose powdery contaminates or other coatings. Cleaning can be accomplished by:
1. Abrasive blasting equipment using dry, hard sharp sand or grit to remove contaminates.



Pocono Fabricators

160 Gamma Drive, Pittsburgh, PA 15238-2989
Phone (610) 400-1885 Fax (610) 400-1863

www.pre-krete.com
info@pre-krete.com

2. High pressure water blaster is acceptable if it can clean the concrete so it will exhibit a tight cohesive surface suitable for bonding of mortar lining.
 - b. In vessels holding liquid, any cracks or leaks shall be repaired prior to installing the lining.

MIXING

Pre-Krete is mixed at the rate of to 1 gallon of water per 50-lb. bag. The amount of water required is dependent on the weather conditions. On hot days, more water is needed than on damp days. Formula G-8 usually requires slightly less mixing water than C-17. Do not add all the water at one time. Start off with about gallon of water and add more as required. Mix the Pre-Krete to a normal, mortar-like consistency. Do not get the Pre-Krete too dry or too soupy. If necessary, add more Pre-Krete to a watery mixture. The consistency should be such that if you put a quantity of Pre-Krete (about the size of a golf ball) on your fingers press it down lightly, then turn your hand over -- the Pre-Krete should stay adhered to your fingers.

EXPANDED METAL

- a. The expanded metal shall be 3/4" x 12 - 14 gage, carbon steel, unflattened, standard diamond pattern expanded metal lath.
- b. Fasten expanded metal tight against concrete on 12" centers, vertically and horizontally by installing a 3/16" or " wedge type anchor as manufactured by Hilti or equivalent.
- c. The long dimension of the expanded metal must run horizontally and the top diamond must overlap the bottom diamond so that the strands slope down into the steel surface. Expanded metal must be tight against the steel so that it does not move up and down when lining over it.

APPLYING MORTAR LINING BY HAND TROWELING

- a. Trowel mortar lining into place working to a final thickness of 3/4" - 1". Use two coats. Second coat must be applied while the first coat is still tacky. Round off any corners and protect any edges with flat iron or angle bar.



Pocono Fabricators

160 Gamma Drive, Pittsburgh, PA 15238-2989
Phone (610) 400-1885 Fax (610) 400-1863

www.pre-krete.com
info@pre-krete.com

- b. After final troweling, sweep surface lightly using a cement brush dipped in water.

APPLYING MORTAR LINING BY GUN OVER EXPANDED METAL

- a. The lining shall be air placed to a thickness of 3/4" - 1" making several continuous passes until the specified thickness is deposited. The mortar lining shall be placed as dry as possible with a minimum water content. The anchoring system must be covered by a minimum of 1/2" of mortar lining.
- b. If the surface of the mortar lining is uneven or porous after being air placed, it may be wiped while damp with a cement brush dipped in water to even out the hills and valleys. No sharp irregularities in the surface of the mortar lining will be permitted. Inside angles shall be rounded smoothly. Any exposed edges of the mortar lining shall be protected by means of a flat bar, the width of the lining, welded in so that the mortar lining can butt against it.
- c. The application of the mortar lining is to be made with either a wet or dry mix gun. The size, specifications and operating procedure must be in accordance with the recommendations of the manufacturer of the equipment. Only competent and experienced personnel who are thoroughly familiar with the pneumatic application of mortar linings shall be employed in the application of this lining.
- d. Under no circumstances is any rebound material to be used. If working from the top down in vertical areas, blow rebound out from behind the expanded metal before applying mortar lining.
- e. At the end of each days work, or if a lengthy work stoppage occurs, the mortar lining in place shall be undercut to the expanded metal at a point where full thickness has been applied. The mortar lining behind the expanded metal should be scored and loose material removed and discarded. Loose rebound material should not be permitted to accumulate and harden.

CURING

Pre-Krete Systems may be cured according to the following methods:

1. CURING COMPOUND



Pocono Fabricators

160 Gamma Drive, Pittsburgh, PA 15238-2989
Phone (610) 400-1885 Fax (610) 400-1863

www.pre-krete.com
info@pre-krete.com

NOTE: CONCRETE SEALER SHOULD NOT BE USED IN POTABLE WATER SERVICE.

Use of a resin-based membrane compound such as CONCRETE SEALER as manufactured by Pocono Fabricators can be spray, brush, and/or roller applied to the fresh mortar lining. It should be applied as soon as possible after the surface moisture has disappeared. Coverage is approximately 150-200 sq. ft./gallon. Mortar lining should be allowed to set untouched for 24 hours.

2. MOISTURE CURE

Pre-Krete Systems can be moisture cured by creating a moist environment within the lined equipment. This is done by securely covering **ALL** manholes and nozzles with plastic and tape. It is imperative that **ALL** openings be tightly sealed. In large equipment, a punctured garden hose producing a fine mist or a simple garden sprinkler of the oscillating type can be placed in the upper elevations of the equipment. This will also create the moist environment required. In extreme conditions of very low humidity (less than 40%) and high temperatures (skin temperature above 90°F) humidifiers are required to prevent water loss during application. This equipment is also known as swamp coolers. If you have difficulty finding this type of equipment in your area, contact Pocono Fabricators.

3. IMMERSION CURE

After the tank is completely lined, let it set untouched for 4 to 8 hours. After the lining has gotten firm, **SLOWLY** fill the tank with water, making sure you are not "washing out" any of the lining. Allow the lining to set for 12 to 24 hours completely immersed in water. Drain and flush the tank. The tank is now ready to be placed into service.

4. HEAT-UP PROCEDURE

When a Pre-Krete lining is installed in a tank, boiler stack, breeching, etc., there is always some residual moisture remaining after a 24-hour curing period. When operating temperatures are above 250°F and a 5 to 7 day cure at 60°F is unattainable, it is important that the installed Pre-Krete lining be heated up gradually so that the residual moisture is not steamed. This could result in spalling and other damage. The following heat-up procedure is only required when a newly lined unit is first placed into service: After you apply the lining allow it to cure for 24 hours using Polyseal or allowing it to set in a moisture laden atmosphere. After that time, bring the temperature up to 250°F and allow it to remain there for 1



Pocono Fabricators

160 Gamma Drive, Pittsburgh, PA 15238-2989
Phone (610) 400-1885 Fax (610) 400-1863

www.pre-krete.com
info@pre-krete.com

hour, then increase the temperature by 50°F and again hold for 1 hour for each inch of thickness. Continue that procedure until you reach the operating temperature.